



Part No.	Description	Fig.
20-6054	Steel headband (DMH)	1
42-6035	Headband cushion (SMH)	2
40-6501	Outer headband holder	3
40-6502	Inner headband holder	4
40-6511	Adjustment bellows	6
17-6081	Grommet, headband clutch	7
31-6068	Screws, headband holder& clutch	8
34-6094	Strain relief, cable entry	9
17-6020	Clamping ring, strain relief	10
18-6052	Fabric dust cover, earspeaker	11
42-6035	Headband cushion (DMH)	12
84-7123	Earspeaker 40Ohm	13
84-7115	Earspeaker 100Ohm	13
84-7112	Earspeaker 400Ohm	13
51-6043	Standard cable, per foot	14
45-6226	Label holder, right and left	15
40-6438	Headband clutch	16

N/S Part not shown on diagrams

Part No.	Description	Fig.
41-6015	Ear cushion, standard, right	17
40-6499	Right ear housing (DMH)	18
40-6500	Left ear housing w/mic. boom	19
37-6317	Microphone cable (in boom)	20
40-6505	Sliding cover, microphone housing	21
21-6017	Steel cable insert, boom	22
31-6067	Screw, microphone housing	24
40-6861	Microphone housing, lower section	25
84-6004	Microphone, dynamic, 200Ohm	26
16-6318	Felt disk, under microphone	27
84-6002	Microphone housing, upper, w/grill	28
41-6041	Ear cushion, standard, left (SMH)	29
42-6043	Foam pad for 40-6578 (SMH)	31
40-6578	Inner headband holder (SMH)	32
20-6076	Steel headband (SMH)	36
37-6198	Cable, through headband (DMH)	N/S
41-6034	Ear cushion, high noise, left	N/S
41-6059	Ear cushion, high noise, right	N/S
51-6063	Split cable, per foot	N/S
P9897	Mic., electret, noise-canceling	N/S
64-6266	Y-cable w/broadcast connectors	N/S